

Vanguard Applications Ware Installing Patches Advisory Notice

Introduction

This notice contains information on how to upgrade the bootprom and install patches which include Service Pak 6.2.S100 and based on Vanguard Applications Ware Release 6.2.R000.

Bootprom and Custom Images

Bootprom and Custom images can be downloaded using Vanguide.

Upgrade Bootprom Using Vanguide and Install the Patch Executable File

Follow these steps to upgrade the Vanguard V340 and V342 bootprom using Vanguide, and install the patch executable file:

Vanguide Instructions

Step	Action									
1	If you have not already done so, install Vanguard Software Builder from any Vanguide Release 6.2.R000 CD-ROM (Part Number 72608-31 A).									
2	Download the V62T1**.ZIP file (where ** represents a number or letter, for example: 1A) from Vanguard Managed Solutions, please save the file to a local drive on your computer.									
3	Use WinZip® to extract the ZIP file. The V62T1**.ZIP file contains the V62T1**.EXE, bootprom_v340_cldr.xrc, bootprom_2lan_v340_cldr.xrc file, and a copy of this advisory notice in PDF format.									
4	Use the Vanguard Terminal via COM port to download the *.xrc file for a selected platform bootprom upgrade: <table><thead><tr><th>Platform</th><th>Bootprom Version</th><th>Filename</th></tr></thead><tbody><tr><td>V340</td><td>1.1.1</td><td>bootprom_v340_cldr.xrc</td></tr><tr><td>V342</td><td>2.1.1</td><td>bootprom_2lan_v340_cldr.xrc</td></tr></tbody></table>	Platform	Bootprom Version	Filename	V340	1.1.1	bootprom_v340_cldr.xrc	V342	2.1.1	bootprom_2lan_v340_cldr.xrc
Platform	Bootprom Version	Filename								
V340	1.1.1	bootprom_v340_cldr.xrc								
V342	2.1.1	bootprom_2lan_v340_cldr.xrc								



T0263-02 A

Vanguide Instructions

Step	Action
5	Run or open the V62T1**.EXE executable file from your local drive.
6	The patch executable file prompts you with installation instructions. Insert the Vanguide 6.2.R000 CD-ROM into the CD-ROM drive and select its drive letter. Follow the installation instructions provided by the installer.

■Note

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).

Build an Image

After you install the patch executable file, you must build and load a custom patch image. This table provides general instructions for these procedures:

Step	Action
1	Using Vanguard Software Builder, build a custom patch image by selecting the appropriate patch (V6.2.T1** for example) from the Release drop-down menu. Select features or options that you want to include in the image.
2	Load the custom image using the Vanguard Software Loader.

■Note

For more detailed patch installation instructions, refer to the *Vanguard Software Builder Manual* (Part Number T0030).
